

102038 Board Wiring

J4 & J5 – Motor

J2 – Ground

J6 & J7 – Supply Cord (only connected on some models)